



recycled rubber care and maintenance instructions

cleaning and maintenance instructions

note:

Sealing the floor is not a necessary step and in fact, it is discouraged in very abusive applications (e.g., Health club free weight area or ice hockey perimeter flooring). However, high color percentage floors (>50%) or areas that experience foot traffic only will greatly benefit by being sealed.

maintenance for un-sealed floors.

- ecofinishes Rubber Flooring can be cleaned much like carpeting.
- Daily vacuuming is encouraged to keep dust to a minimum.
- If the flooring cannot be fully cleaned with a vacuum, a damp mopping with a mild soap and water solution will usually be sufficient.
- It is important not to get the flooring too wet as this may have an adverse affect on the adhesive system employed.
- Change the soap and water solution often!
- Use a wet vacuum to remove excess water from the flooring.
- Be sure to use a clean mop. This will keep your floor smelling fresh and clean.

post construction maintenance for sealed floors.

- Sweep the floor clean.
- Dry vacuum to ensure any fine soil is removed.
- Wet scrub floor with TASKI Profi cleaner (6-8 oz / gal of water) using buffer or autoscrubber with a TASKI contact pad or soft nylon brush.
- TASKI floor care products are manufactured by JohnsonDiversey™ and can be found at many janitorial supply houses.

- JohnsonDiversey™ customer service hotline is 800-626-5015
- Look under institutional floor care products on their website at <http://www.diverseylever.com>
- Recover soiled solution, rinse, and allow to dry thoroughly (6-8 hours).

initial treatment

- Apply 3 thin coats of TASKI Vision Matte
- Allow proper drying time before applying next coat.

note:

Apply floor finish with synthetic wax mop. While the finish is wet, buff the floor with floor buffer (150-300 rpm) and soft nylon brush. This application drives the finish into the floor and prompts proper sealing and coating of the floor.

recycled rubber care and maintenance instructions

- Daily / As Needed Cleaning
- Dry vacuum floor thoroughly (daily).
- Auto scrub or wet mop floor using TASKI Combiplus or TASKI Wiwax as needed. (2-3 oz/gl of water).

note:

In an office environment, the floor may become scuffed due to heavy foot traffic and may require weekly or as needed spray buffing or dry buffing of the floor with a mint or white pad. In application of spray buffing, use TASKI Wiwax diluted 50/50 with water.

periodic cleaning as needed

- Dry vacuum the floor thoroughly.
- Wet scrub the floor with TASKI Profi (4oz / gl). This application is done with an autoscrubber or a buffer and wet vacuum. Use a TASKI purple pad for scrubbing the floor.
- Allow the solution to remain on the floor for at least 5 minutes.
- Wet vacuum soiled solution.
- Rinse and allow to dry (1-2 hours).
- Apply 1-2 thin coats of TASKI Vision Matte using a wet buffing process with soft nylon brush.

a few tips about working with ecofinishes rubber flooring

- Use a vacuum with a high CFM to pick up dust.
- Wait for the floor to dry between applications of floor finish or sealer.
- Apply floor finish (thin coats) with wax mop and follow with a floor buffer using a soft nylon brush.
- For large areas, use an autoscrubber with a contact pad or soft nylon brush to clean the floor daily.
- For stripping a rubber floor, use TASKI Ice-It and nylon brush.
- For poorly maintained floors, it may be necessary to continue cleaning with Ice-It for an extended period.
- For food areas, daily cleaning should be done with Profi (2-4 oz/gl).